



COMMISSIONING OF ELECTRIC ONLY RADIATORS

This guide is designed for use with radiators purchased as “pre-filled” or “Electric Only” and carrying the  or  symbols. It applies to both Standard and thermostatic elements. The instructions below are not required for “Dual Fuel” installations.

It is imperative that the following steps are carried out on first use of the radiator.

Failure to follow these procedures will result in **permanent damage** to the element.

After installing the element, mounting the radiator and your electrician has made the final connections, please follow these simple steps. You will require a towel or similar to collect the small amount of fluid excess.

1. Open the bleed valves at the top of the radiator
2. Turn on the element.
3. A small amount of fluid will ooze from the bleed valve use a towel or similar to collect this excess.
4. Once excess fluid has stopped or after twenty minutes, close the bleed valve.
5. Turn off the element.

The radiator has now been commissioned and is ready to use. Should the element in the radiator be replaced at any time then this procedure will need to be repeated.